

# Extension

Installation

Hardware Brand:  
**Hoppe**



Loosen the set screw on the **INSIDE** door handle. Pull off the handle and save the nylon washer. Then pull off the outside door handle with the spindle attached.



Loosen the **OUTSIDE** handle set screw and remove the handle, noting how far the spindle goes into it. Insert the **NEW** spindle at the same distance, making sure that the grooved side faces the set screw.



Replace the **OUTSIDE** handle with the new spindle back into the door. Place the saved nylon washer on the new spindle.



Install the **ENCI Extension**, followed by the **NEW** nylon washer, and the **INSIDE** handle. The grooved side of the new spindle should line up with the set screw.



Gently push both the inside and outside handles together and tighten the inside set screw. Make sure that the handles turn freely but not loosely.

A product of  
Ed Nelson Construction, Inc.  
15150 E Sundance Court  
Wichita, KS 67230-7172



Online at  
[www.enci.us](http://www.enci.us)  
© ENCI. All rights reserved.

Questions? Get in touch with Ed.  
316.733.6553 ■ 316.641.0114 ■ [enci@enci.us](mailto:enci@enci.us)