

Extension Installation

Hardware Brand: Hoppe Inactive



Place the washer on the bolt.



Insert the bolt through the square hole on the BACK of the escutcheon plate.



Fit the extension over the bolt. Line up the square projection of the extension over the square hole in the escutcheon plate.



Seat the handle in the square hole of the escutcheon plate.



Use a 3/4-inch or 19mm socket to tighten the bolt.



Make sure that the door handle is perpendicular to the escutcheon plate.



Questions? Get in touch with Ed.
316.733.6553 ▪ 316.641.0114 ▪ enci@enci.us

A product of
Ed Nelson Construction, Inc.
15150 E Sundance Court
Wichita, KS 67230-7172



Online at
www.enci.us

© ENCI. All rights reserved.