

Extension Installation

Hardware Type: **Kwikset Passage Lever**



Because the set screw is reverse threaded, you must turn it COUNTER-CLOCKWISE in order to loosen it. Turn the set screw counter-clockwise until the handle can be pulled off.



Pull off the door handle.



Slide on the DOOR HANDLE EXTENSION. Line up the hole on the barrel of the extension with the set screw. Now turn the set screw CLOCKWISE until the extension is secure.



Replace the door handle. Line up the hole in the handle over the set screw of the extension. Turn the screw COUNTER-CLOCKWISE until the door handle is secure.



Questions? Get in touch with Ed.
316.733.6553 ▪ 316.641.0114 ▪ enci@enci.us

A product of
Ed Nelson Construction, Inc.
15150 E Sundance Court
Wichita, KS 67230-7172



Online at
www.enci.us
© ENCI. All rights reserved.